




BRUSHES

How to Select the Proper Brush for your Machine

- Find the make and model number of your floor machine starting on page 67 to determine the appropriate block size and clutch plate. General guidelines include:
 - Brushes and long fill pad drivers for a single brush, swing machines are usually 2" smaller than the machine. For instance, a 18" machine will use a 16" block. This is the "block diameter".
 - Short trim pad drivers are usually 1" smaller than the machine. An 18" machine will use a 19" driver. Add 1" to the block size listed for short-trim pad drivers.
- Find the appropriate brush type for your cleaning application by using the Brush Selection Guide on this page.
- After locating the brush type and block size, find the brush part number from the tables on page 70.



Fill Types and Descriptions

- POLY** - An excellent general scrubbing brush that is more durable than plastic and highly resistant. Flexible and good for cleaning narrow grout lines and uneven surfaces. (Black)
- NYLON** - Highly resistant to abrasion with excellent bristle bend recovery, giving it an excellent wear-life. Good for rough surfaces and high temperature conditions. (Black)
- SCRUB-GRIT** - Highly durable, but with minimum aggression. For general scrubbing of rough and resilient floors such as tile, terrazzo, and non-slip epoxy finishes. (Grey, 500 Grit)
- STRIP-GRIT** - For aggressive scrubbing of hard floors such as concrete and stripping finishes from hard surfaces. Also good for cleaning wide grout lines. (Black, 80 Grit)

Applications

Product	Scrubbing								Stripping				
	Carpet Scrubbing	Vinyl Tile	Terrazzo	Marble	Concrete	Ceramic Tile	Non-Slip Epoxy Finish	Linoleum	Concrete	Terrazzo	Vinyl Tile	Ceramic Tile	Linoleum
Poly		■	■		■	■	■	■					
Nylon	■	■	■	■	■	■	■	■					
Scrub-Grit			■	■	■	■							
Strip-Grit									■	■	■	■	■



Brushes

Poly - Black, .028 Bristle Dia., 180 Grit

Block Diameter	11"	12"	13"	14"	15"	16"	17"	18"	19"
Graco #	BRP-11	BRP-12	BRP-13	BRP-14	BRP-15	BRP-16	BRP-17	BRP-18	BRP-19

Nylon - Black, .028 Bristle Dia., 46 Grit

Block Diameter	11"	12"	13"	14"	15"	16"	17"	18"	19"
Graco #	BRN-11	BRN-12	BRN-13	BRN-14	BRN-15	BRN-16	BRN-17	BRN-18	BRN-19

Scrub-Grit - Grey, .018 Bristle Dia., 500 Grit

Block Diameter	11"	12"	13"	14"	15"	16"	17"	18"
Graco #	BRSC-11	BRSC-12	BRSC-13	BRSC-14	BRSC-15	BRSC-16	BRSC-17	BRSC-18

Strip-Grit - Black, .050 Bristle Dia., 80 Grit

Block Diameter	11"	12"	13"	14"	15"	16"	17"	18"	19"
Graco #	BRS-11	BRS-12	BRS-13	BRS-14	BRS-15	BRS-16	BRS-17	BRS-18	BRS-19

Pad-Drivers

Block Diameter	11"	12"	13"	14"	15"	16"	17"	18"	19"
Graco #	BRPD-11	BRPD-12	BRPD-13	BRPD-14	BRPD-15	BRPD-16	BRPD-17	BRPD-18	BRPD-19

Tri-Lok Pad-Drivers

Block Diameter	15"	16"	17"	18"	19"	20"
Graco #	PD-15	PD-16	PD-17	PD-18	PD-19	PD-20

Tri-Lok Pad-Drivers

With a unique "all-in-one" design, the Tri-Lok Pad Driver offers fast installation with quick, yet effective, driving action. Revolutionary in that it combines the NP-92 clutch plate, built-in riser and a triangular showerfeed system, this pad driver is cost-effective and can handle even the toughest jobs.

- Fits more than 600 single-disc rotary floor machine models
- Triangular showerfeed system with a smooth wall delivers over 50% more solution to the floor.
- Drives all standard or economy floor pads and bonnets.
- Water and chemical resistant engineered floor block.



Brushes - Machine Listings

Below are the listings to help you select the correct block size and clutch plate for your machine. When using this listing, please keep in mind that:

- Scrubbing brushes and long-trim pad drivers are generally 2" smaller than the machine: this is the 'block diameter' that is listed in the table.
- To calculate the size for a short-trim pad driver, add 1" to the block size listed in the table.

Please call Customer Service for information on machines not listed.

Manufacturer's Model number	Block Dia.	Plate #	Manufacturer's Model number	Block Dia.	Plate #
Alto/Clarke			Alto/Clarke Cont.		
820	19"	NP-92	Leader 2400 - H.S Pad Driver	13"	CALL
1700 Mini-Scrubber	17"	CALL	Leader 3200, 3400- H.S Pad Driver	17"	CALL
2000 Mini-Scrubber	18"/19"	CALL	MP-18	16"	NP-92
2000B, 2000E	18"/19"	CALL	Mini Scrubber 1700	16"/17"	CALL
2400	13"	CALL	Mini Scrubber 2000	18"/19"	CALL
3200, 3400	17"	CALL	P-11	9" - 3-3/8" CH	CALL
Burnisher 1000, 1500, 2000 - H.S. Pad Driver	18"	CALL	P-12	10" - 1-3/4" CH	CALL
Burnisher 2000B - H.S Pad Driver	19"	CALL	P-13	11"	NP-92
C-15	13"	NP-92	P-15	13"	NP-92
C-16, C-1600	14"	NP-92	P-17	15"	NP-92
C-18, C-1800	16"	NP-92	P-20	18"	NP-92
C-20, C-2000	18"	NP-92	PE-20	19"	NP-92
C-22	20"	NP-92	P-22	20"	NP-92
C2K 13	11"	NP-92	P-23	21"	NP-92
C2K 16, 160, 1600, 1600 HS, 1600 DS	14"	NP-92	S-13	11"	NP-92
Compact Leader 1700	16"/17"	CALL	S-16	14"	NP-92
E-15	13"	NP-92	S-18	16"	NP-92
EM-16	14"	NP-92	S-20, SS-20	18"	NP-92
E-18	16"	NP-92	TB-18	9" - 2-1/2" CH	CALL
Encore L20, S20, S20E	18"/19"	CALL	TB-20E, TB-21E	10"	CALL
Encore L28, S28	14"	CALL	TB-60 - H.S Pad Driver	13"	CALL
Encore L33, S33, R34	17"	CALL	TB-80 - H.S. Pad Driver	17"	CALL
Encore L38, R38, S38	19"	CALL	VP-16	14"	NP-92
Encore L2426	13"	CALL	VP-18	16"	NP-92
Encore S2426	13"	CALL	VP-20	18"	NP-92
FM-11, FM-1100D	9" - 3-3/8" CH	CALL	Vision 17	16"/17"	CALL
FM-12, FM-12R	9" - 3-3/8" CH	CALL	Vision 20	18"/19"	CALL
FM-13, FM-1300	11" - 3-3/8" CH	CALL	Vision 21	11"	CALL
FM-13	11"	NP-92	Vision 26	14"	CALL
FM-14	12"	NP-92	Vision 32	17"	CALL
FM-15, FM-1500	13"	NP-92	Vision 38	19"	CALL
F-16, FM-16	14"	NP-92	Vision 3400	17"	CALL
FM-17, FM-1700	15"	NP-92	Vision V	13"	CALL
FM-18	16"	NP-92			
FM-20, FM-2000	18"	NP-92			
FM-23, FM-2300	21"	NP-92			
GM-15	13"	NP-92			
GM-17	15"	NP-92			
GM-18	16"	NP-92			
LP-80, LP-136	15"	NP-92			
Leader 1700, Compact	16"/17"	CALL			
Leader 2000	18"/19"	CALL			

Brushes

Brushes - Machine Listings



Brushes

Manufacturer's Model number	Block Dia.	Plate #
American/Lincoln		
22	20"	NP-92
66	14"	CALL
81	17"	CALL
121	19"	NP-92
151, 156, 161	14"	NP-92
150 Series	12"	NP-92
152 Series	17"	NP-92
153 Series	21"	NP-92
160 Series	12"	NP-92
161	14"	NP-92
162 Series	17"	NP-92
189	15"	NP-92
191-11, 191-15	13"	NP-92
192, 198	15"	NP-92
193 Series	12"	NP-92
197 Series	13"	NP-92
215, 216	14"	NP-92
221, S221	19"	NP-92
301	18"	NP-92
317	15"	NP-92
319	17"	NP-92
320	18"	NP-92
321	19"	NP-92
322	20"	NP-92
518 Series Sectional	L250	CALL
524 Series Sectional	L250	CALL
530 Series Sectional	L250	CALL
537, 538 Sectional	L250	CALL
560 Series Sectional	L250	CALL
620 Series Sectional	L250	CALL
721	19"	NP-92
721 Sectional	L250	CALL
726	13" - 4"CH	CALL
730	14" - 4"CH	CALL
730 Sectional	L250	CALL
750 Sectional	L250	CALL
772 Sectional	L250	CALL
930i	14"	CALL
930i Sectional	L250	CALL
934	17"	CALL
934 Sectional	L250	CALL
936	17" -4"CH	CALL
936 Sectional	L250	CALL
950, 960	14"	CALL
950, 960 Sectional	L250	CALL
1030	14"	CALL
1030 Sectional	L250	CALL
6200, 6700	14"	CALL
BP21 Sectional	L250	CALL
BETCO		
FL 17, HD, DS	15"	NP-92
FL 19, HD, DS	17"	NP-92

Manufacturer's Model number	Block Dia.	Plate #
Breuer/Tornado		
15	13"	CALL
17	15"	CALL
19	17"	CALL
20-1	18"	CALL
22	20"	CALL
73 Series	12" - 5" CH	CALL
75 Series	14" - 5" CH	CALL
77 Series	16" - 5" CH	CALL
94 Series	12"	CALL
96, 97	14"	CALL
98	16"	CALL
130, 131, 132	11" - 4" CH	CALL
280-15, 283-15	13"	CALL
280-17, 283-17	15"	CALL
280-19, 283-19	17"	CALL
280-22, 283-22	20"	CALL
940 Series, 941	12"	CALL
960, 961, 962	14"	CALL
980, 981	16"	CALL
990	20"	CALL
6200, 6300	10" - 5" CH	CALL
6400, 6500	12" - 5" CH	CALL
6600, 6700	14" - 5" CH	CALL
6800, 6900	16" - 5" CH	CALL
95625 (21" Auto-Mite)	19" - 4-5/8" CH	CALL
95678/95679 (16" Auto Mite)	14" - 4-5/8" CH	CALL
97800 (16" Series I)	14"	CALL
97805 (18" Series I)	16"	CALL
97810 (20" Series I)	18"	CALL
97820 (14" Series I)	12"	CALL
98405 (17" Series II)	15"	CALL
98410 (19" Series II)	17"	CALL
98415 (22" Series II)	20"	CALL
98440 (Glazer 700/1500)	18"	CALL
98441 (Glazer 1100, 1600)	18"	CALL
98445 (Glazer 1100, 1400)	18"	CALL
98457 (Glazer 1500)	18"	CALL
98470 (16" Bi-Speed)	14"	CALL
98473 (17" Bi-Speed)	15"	CALL
98480 (20" Bi-Speed)	18"	CALL
98653 (Tri-Drive 1017)	15"	CALL
98656 (Tri-Drive 1020)	18"	CALL
98663 (Tri-Drive 1517)	15"	CALL
98666 (Tri-Drive 1520)	18"	CALL
98672 (17" ES Deluxe)	15"	CALL
98673 (ES8673 - 17" Deluxe)	15"	CALL
98674 (20" ES Deluxe)	18"	CALL
98675 (ES8675 - 20" Deluxe)	18"	CALL
98677 (1517SSM)	15"	CALL
98682 (ES8682 - 17" Standard)	15"	CALL



Brushes - Machine Listings

Brushes

Manufacturer's Model number	Block Dia.	Plate #
Breuer/Tornado Cont.		
98683 (ES8683 - 17" Standard)	15"	CALL
98684 (ES8684 - 20" Standard)	18"	CALL
98685 (ES8685 - 20" Standard)	18"	CALL
99125 (EZ-20 Floorkeeper)	20"	CALL
99130 (EZ-24 Floorkeeper)	22"	CALL
99300 (Floorkeeper 3800)	11"/12"	CALL
99307 (26" Floorkeeper)	14"	CALL
99321 (26" Floorkeeper)	12"/13"	CALL
99351 (28" Floorkeeper)	14"/15"	CALL
99407 (33" Mid-Range Floorkeeper)	16"/16-12"	CALL
99421 (32" Long-Range Floorkeeper)	16"/16-12"	CALL
99430 (30" Floorkeeper)	16"	CALL
99450, 99451 (36" Long-Range Floorkeeper)	18"	CALL
Champion	10"	CALL
Cyclone 14-1/2	12"	CALL
Cyclone 16-1	14"	CALL
Cyclone 18-1	16"	CALL
Jumbo	14" - 6-1/8" CH	CALL
Majestic	18" - 6-1/8" CH	CALL
Royal	12" - 5-1/4" CH	CALL
Standard	16" - 6-1/8" CH	CALL

Factory Cat/TomCat		
21, 2100	10"	CALL
25, 2500	12"	CALL
27, 2700	13"	CALL
29	14"	CALL
35	16"	CALL
38, 40, 40HD, 3700	18"	CALL
52, 5100	17"	CALL
SS1017, SS1517HD	15"	NP-92
SS1517-2S		
SS1020, SS1520, SS1520-2S	18"	NP-92

General		
1000 - high speed driver	18"	CALL
2000DC - h.s.d	18"	CALL
GF-15	13"	NP-92
GF-17, GVS-17	15"	NP-92
GF-19, GVS-19	16"	NP-92
GF-21, GVS-21	18"	NP-92
GF-23	20"	NP-92
K-12, KC-12, KR-12	11"	NP-92
KL-13, KR-13	11"	NP-92
KC14DHS	11"	NP-92

Manufacturer's Model number	Block Dia.	Plate #
General Cont.		
K-14, KC-14, KL-14, KR-14	13"	NP-92
K-15, KL-15	13"	NP-92
KC16DHS	14"	NP-92
K-16, KC-16, KL-16, KR-16	15"	NP-92
KC-17, KL-17, KR-17	15"	NP-92
KC18DHS	16"	NP-92
K-18, KC-18, KR-18	16"	NP-92
KC20DHS	18"	NP-92
KC-20, KR-20	18"	NP-92
K-22, KC-22, KR-22	20"	NP-92
S-11	10"	NP-92
S-13	11"	NP-92
S-15	13"	NP-92
S-18	16"	NP-92
S-22	20"	NP-92

Graco		
Saturn 24" Sectional	C240	CALL
Saturn 32" Sectional	C370	CALL

Hawk		
HP 1017, HP 1517HD	15"	NP-92
HP 1020, HP 1520HD	18"	NP-92

Kent		
170E	15"	NP-92
A-11	9" - 5" CH	CALL
C-13, 13"	11" - 5-5/8" CH	CALL
C-13, 15"	14" - 5-5/8" CH	CALL
C-15	15" - 5" CH	CALL
C-18	17" - 5" CH	CALL
D-20	19 - 5" CH	CALL
E-12, E-13	11"	NP-92
GA-15	13"	NP-92
GA-17	15"	NP-92
GA-20	18"	NP-92
K-11	9" - 5" CH	CALL
K-12, KM-13	11" - 5" CH	CALL
K-13, K-14	11" - 5" CH	CALL
K-15, K-16	14" - 5" CH	CALL
K-17, K-17HD	15" - 5" CH	CALL
KA-17 Select Scrub	15"	NP-92
KA-18, KB-18	9" - 1-7/8" CH	CALL
KA-20	10"	CALL
KA20BT, KA-20E, KA-20B	19"	NP-92
KA-26	12" 1-7/8" CH	CALL
KA-26BT	12"/13"	CALL
KA-26HD	13" - 1-7/8" CH	CALL
KA-27 Dura Scrub	13"/14"	CALL
KA-27SS, KA-27SSA	13"/14"	CALL
Select Scrub		CALL
KA-32	15" - 1-7/8" CH	CALL
KA-33 Dura Scrub	16"/17"	CALL
KA-33BR	16"	CALL
KA-33SS, KA-33SSA	16"/17"	

Brushes - Machine Listings



Brushes

Manufacturer's Model number	Block Dia.	Plate #
Kent Cont.		
Select Scrub		CALL
KA-34BR2	16"	
KA-39 Dura Scrub	19"/20"	CALL
KA-39SS, KA39SSA	19"/20"	CALL
Select Scrub		NP-92
KA-171B	15"	
KA-200E, KA-201BST	10" - 1-7/8" CH	CALL
KA-261, KA-262B, KA-265	13" - 1-7/8" CH	CALL
KA-325B	15" - 1-7/8" CH	CALL
KA-326EB, 32ERB2, KA-36	15" - 1-7/8" CH	CALL
KA-381EB, 38ERB2, KA-38	18" - 1-7/8" CH	CALL
KA-382	18" - 1-7/8" CH	CALL
KA-3818	18" - 1-7/8" CH	CALL
KA-382	18" - 1-7/8" CH	CALL
KA-3818	18" - 1-7/8" CH	CALL
KE-20	10"	NP-92
KF-13DL, KF-13SL	11"	NP-92
KF-17DL, KF-17SL	15"	NP-92
KF-1SL2 (2 Speed)	15"	NP-92
KF-20DL, KF-20HD, KF-20SL	18"	CALL
KF-20SL2	18"	NP-92
K-130, KF-130	11"	NP-92
KF-150A	13"	NP-92
K-170, KF-170A, KF-174SL, KF-175A	15"	CALL
KF-175SA - H.S Pad Dr.	15"	NP-92
KF-176SL2	15"	NP-92
KF-195, KF-195M	18"	NP-92
KF-200A, KF-201, KF-204SL	18"	CALL
KF-204SC	18"	NP-92
KF-205A, KF-206SL2	18"	NP-92
KF-205S2 (2 Speed)	18"	NP-92
M-13, MA-13	11"	NP-92
M-15, XP-15	13"	NP-92
M-17, MA-17, XP-17	15"	NP-92
M-20, MA-20, XP-20	18"	NP-92
M-23, MA-23, XP-23	21"	CALL
Razor 17	16"	CALL
Razor 20	19"	CALL

Manufacturer's Model number	Block Dia.	Plate #
Mastercraft		
1300, 3300	11"	NP-92
1550, 1575, 2550	13"	NP-92
1700, 1775	15"	NP-92
1900, 3990	17"	NP-92
3550, 3575, 4550, 4575	13"	NP-92
3700, 3775, 4775	15"	NP-92
MBS-2000E - h.s.d	18"	CALL
MD-13A	11"	NP-92
MD-15B, C, D	13"	NP-92
MD-17	15"	NP-92
MD-20, D, E	18"	NP-92
MD-21	19"	NP-92
MD-24E	22"	NP-92
MHS20E - h.s.d	18"	CALL

Minuteman		
18	16"	NP-92
21	10" - 4" CH	CALL
24	12" - 4" CH	CALL
24B	12"	CALL
26B	13"	CALL
32	15" - 4" CH	CALL
32B	16"	CALL
38B	19"	CALL
170, 175	16"	CALL
200, 205	19"	CALL
260B, 265B	13"	CALL
320, 340	16"	CALL
B43	16"	CALL
B53	19"	CALL
Deluxe-16, D-16, D-16HD	14"	NP-92
Deluxe-20, D-20, D-20HD	18"	NP-92
Deluxe-24, D-24	22"	NP-92
Frontrunner 15	13"	NP-92
Frontrunner 17	15"	NP-92
Frontrunner 20	18"	NP-92
Hi-Buffer - H.S Pad Driver	19"	CALL
Lite-12	10"	NP-92
Lite-13	11"	NP-92
Lite-14	12"	NP-92
M-17	15"	NP-92
M-20	18"	NP-92
MC-12, MCS-12	10"	NP-92
MC-14, MCS-14	12"	NP-92
MC-15	12"	NP-92
MC-16, MCS-16, MC-EX-16	14"	NP-92
MC-19, MCS-19	17"	NP-92
MC-22, MCS-22	20"	NP-92
MC-31	10"	NP-92
MC-1100 - H.S Pad Dr.	19"	CALL
PR20E	17"	NP-92



Brushes - Machine Listings

Brushes

Manufacturer's Model number	Block Dia.	Plate #
Minuteman Cont.		
SBR-50	10" - 5.53" CH	CALL
SBR-60	12" - 5.53" CH	CALL
SBR-70	14" - 5.53" CH	CALL
SBR-85	17" - 5.53" CH	CALL
SBR-100	19" - 5.53" CH	CALL
Special-17, S-17, S-17HD	15"	NP-92
Special-20, S-20, S-20HD	18"	NP-92
V-13	11"	NP-92
V-16	14"	NP-92
V-18	16"	NP-92
V-20	18"	NP-92
V-23	21"	NP-92
Nilfisk/Advance		
All Purpose Matador 17	15"	NP-47
All Purpose Matador 20	18"	NP-47
BA5321, BA 5321D	19"	CALL
Converta Max 20	19"	CALL
Converta Max 26	12" - 5.53" CH	CALL
Converta Max 28	14" - 5.53" CH	CALL
Converta Max 34	16" - 5.53" CH	CALL
Convertamatic 17	15"	NP-47
Convertamatic 18	16" - 5.53" CH	CALL
Convertamatic 20	18"	NP-47
Convertamatic 21	19" - 5.53" CH	CALL
Convertamatic 24	11" - 5.53" CH	CALL
Convertamatic 26	12" - 5.53" CH	CALL
Convertamatic 28	14" - 5.53" CH	CALL
Convertamatic 32	16" - 5.53" CH	CALL
Convertamatic 38	19" - 5.53" CH	CALL
Convertamatic 200	18"	NP-47
Convertamatic 240	11" - 5.53" CH	CALL
Convertamatic 260, 265	12" - 5.53" CH	CALL
Convertamatic 280, 285	14" - 5.53" CH	CALL
Convertamatic 320, 325	16" - 5.53" CH	CALL
Convertamatic 380, 385	19" - 5.53" CH	CALL
3800		
Galaxie 14	12" - 4-29/32" CH	CALL
Galaxie 16	14" - 4-29/32" CH	CALL
Galaxie 16, 160	14"	NP-47
Galaxie 18	16" - 5" CH	CALL
Galaxie 18, 180	16"	NP-47
Galaxie 20	18"	NP-47
Hydro-Cat	12" - 5.53" CH	CALL
Hydro-Retriever 200	18"	NP-47
Hydro-Retriever 240	11" - 5.53" CH	CALL
Hydro-Retriever 2800	14" - 5.53" CH	CALL
Hydro-Retriever 3200	16" - 5.53" CH	CALL
Hydro-Retriever 3800	19" - 5.53" CH	CALL
Lynx 285	14" - 5.53" CH	CALL
Lynx 325	16" - 5.53" CH	CALL
Lynx 385	19" - 5.53" CH	CALL
MP-20 HS	18"	NP-47
Matador 17	15"	NP-47
Matador 20	18"	NP-47

Manufacturer's Model number	Block Dia.	Plate #
Nilfisk/Advance Cont.		
Matador 24	22"	CALL
Micromatic 17B	15"	NP-92
Mobilmatic 17	15"	NP-47
Mobilmatic 20	18"	NP-47
Mobilmatic 64, 6400	15" - 5.53" CH	CALL
Pacemaker 15	13"	NP-47
Pacemaker 17	15"	NP-47
Pacemaker 20, P20E	18"	NP-47
Pacemaker 22	20"	NP-47
Pacemaker 24	22"	CALL
Pacesetter 17	15"	NP-92
Pacesetter 20	18"	NP-92
SD 17, SD 4317	15"	NP-92
SD 20, SD 5120	18"	NP-92
SD 130	11"	NP-92
Shadow 17	15"	NP-92
Shadow 20	18"	NP-92
Spin 17	15"	NP-92
Spin 20	18"	NP-92
Trac 240	11" - 5.53" CH	CALL
Trac 280	14" - 5.53" CH	CALL
Trac 320	16" - 5.53" CH	CALL
Trac 380	19" - 5.53" CH	CALL
Whirlamatic 200	18"	NP-47
Whirlamatic 1100 - high speed pad driver	18"	CALL
NSS		
21	10"	CALL
24B	12"	CALL
Champ 2629	14" - 5.53" CH	CALL
Charger 20, 1500	18"	CALL
Filly 13	11"	NP-92
Maverick II - 15	13"	NP-92
Maverick II - 17,	15"	NP-92
Maverick 300 - 17		
Maverick II - 20,	18"	NP-92
Maverick 300-20		
Maverick 300	18"	NP-92
Mustang 17, 300-17	15"	NP-92
Mustang 20, 300-20	18"	NP-92
Portable 13	11"	CALL
Portable 13-SP	11"	NP-92
SS-13	11"	NP-92
SP-15, SS-15	13"	NP-92
SP-16, SS-16	14"	NP-92
SP-17, SS-17	15"	NP-92
SP-19, SS-19	17"	NP-92
SP-20, SS-20	18"	NP-92
Thoroughbred FP-15	13"	NP-92
Thoroughbred 17	15"	NP-92
Thoroughbred 20	18"	NP-92
Thoroughbred 23	21"	NP-92
Wrangler 17	17"	CALL
Wrangler 20	20"	CALL
Wrangler 24	11" - 5.53" CH	CALL
Wrangler 26	12" - 5.53" CH	CALL

Brushes - Machine Listings



Brushes

Manufacturer's Model number Block Dia. Plate #

NSS Cont.

Wrangler 27	13" - 5.53" CH	CALL
Wrangler 33	16" - 5.53" CH	CALL
Wrangler 1708C	17"	NP-92
Wrangler 2008C	20"	NP-92

Nobles

11	9"	NP-92
21	10" - 4" CH	CALL
24	12" - 4" CH	CALL
32	15" - 4" CH	CALL
260	12-3/4"/13"	CALL
265XP	12"/13"	CALL
320	15"/15-1/4"	CALL
1125LT	9"	NP-92
1400 Series	12"	NP-92
2000 Series	18"	NP-92
2300 Series	21"	NP-92
5300	19"	CALL
EZ Rider HP	14"	CALL
SS-14, SPR-14	12"	NP-92
SS-16, SPR-16	14"	NP-92
SS-17, SPR-17	15"	NP-92
SS-19, SPR-19	17"	NP-92
SS-20, SPR-20	18"	NP-92
SS-22, SPR-22	20"	NP-92
SS-23, SPR, 23	21"	NP-92
SS-1700, SS-1701	15" - 5.53" CH	CALL
SS-2000, SS-2001	19" - 5.53" CH	CALL
SS-2400	11" - 5.53" CH	CALL
SS-2401	11" - 5.53" CH	CALL
SS-2601	12" - 5.53" CH	CALL
SS-2700	13" - 5.53" CH	CALL
SS-2701	13" - 5.53" CH	CALL
SS-3300	16" - 5.53" CH	CALL
SS-3301	16" - 5.53" CH	CALL
SS-5300	19"	CALL

Pacific

13, Satellite 13	11"	NP-92
14	12"	NP-92
15	13"	NP-92
16, Satellite 16	14"	NP-92
17	15"	NP-92
19, 19A	17"	NP-92
PS-20	18"	NP-92
21	19"	NP-92
22	20"	NP-92
23, 23A	21"	NP-92
24	22"	NP-92
PCP-13	11"	NP-92
PCP-15	13"	NP-92
PCP-17	15"	NP-92
PCP-20	18"	NP-92
PCP-23	21"	NP-92
PHS-17	15"	NP-92
PHS-19	17"	NP-92
PHS-200C	18"	CALL

Pullman-Holt

50	14"	CALL
2S-16	14" - 5" CH	CALL
2S-17	15" - 5" CH	CALL

Manufacturer's Model number Block Dia. Plate #

Pullman-Holt Cont.

2S-20	18" - 5" CH	CALL
2S-23	21" - 5" CH	CALL
A-12	9" - 5" CH	CALL
A-14	12" - 5" CH	CALL
A-16	14" - 5" CH	CALL
B-13D	11"	NP-92
B-14D	12"	NP-92
B-16 Series	14"	NP-92
B-18 Series	16"	NP-92
B-20 Series	19"	NP-92
B-22F	20"	NP-92
C-12	9"	NP-92
C-16D, C-16E	14"	NP-92
C-18D	16"	NP-92
C-20 Series	18"	NP-92
C-22F	20"	NP-92
C-24F	22"	NP-92
CD-12	9" - 5" CH	CALL
CD-14	12" - 5" CH	CALL
CD-16	14" - 5" CH	CALL
CH-11	9"	NP-92
D-18F	16"	NP-92
ES2000	18"	NP-92
Expert-13	11"	NP-92
Expert 16	14"	NP-92
Expert 18	16"	NP-92
Expert 20	17"	NP-92
Expert 22	20"	NP-92
Gloss Boss 1090, 1500, 2000 - high speed driver	18"	CALL
Heavy-Duty 15	13" - 4-1/4" CH	CALL
HS18F	16"	NP-92
HST-20	9"	NP-92
J-12A	9"	NP-92
JW-12	10"	NP-92
JW-13	11"	NP-92
JW-16	14"	NP-92
JW-18	16"	NP-92
JW-20	17"	NP-92
JW-22	20"	NP-92
Jubilee 12	9" - 5" CH	CALL
M-13-1/2	11"	CALL
M-15-1/2	13"	CALL
M-16, M-16F	14"	NP-92
M-17	15"	CALL
M-20 Series	18"	NP-92
M-23	21"	CALL
P-12B, P-12C	10"	NP-92
P-12-1/2	11"	NP-92
P-13B, P-13C	11"	NP-92
P-14, PC-14, PR-14	12"	NP-92
P-16, PC-16, PR-16, PX-16	14"	NP-92
P-18, PC-18, PR-18	16"	NP-92
P-20 Series, PES-2000	18"	NP-92
P-22 Series	20"	NP-92
P-24 Series	22"	NP-92



Brushes - Machine Listings

Brushes

Manufacturer's Model number Block Dia. Plate #

Pullman-Holt Cont.		
S-17 Series	15"	NP-92
S-20 Series	18"	NP-92
Scrub Boss SB26	12" - 5-1/8"CH	CALL
Scrub Boss SB32	15" - 5-1/8"CH	CALL
Single 13	11"	NP-92
Single 14	12"	NP-92
Single 16	14"	NP-92
Single, 18, Single 19	16"	NP-92
Single 20	17"	NP-92
Single 22	22"	NP-92
Single 24	21"	NP-92
Special 12	10"	NP-92
Special 16	14"	NP-92
Special 20E	18"	NP-92
Super 12	9"	NP-92
Super 16"	14"	NP-92

SSS		
15	13"	NP-92
16	14"	NP-92
17	15"	NP-92
19, 19A	17"	NP-92
21	19"	NP-92
23, 23A	21"	NP-92

Taski		
Hi Speed	15"	CALL
Combimat 55	11" - 4" CH	CALL
Combimat 85	16" - 4" CH	CALL
1000E	19" - 4" CH	CALL
Combimat 1500	11"	CALL
Combimat 1700	14"	CALL
Combimat 1900	17"	CALL

Tennant		
260, 260XP	12-3/4"/13"	CALL
320	15"/15-1/4"	CALL
426	12" -4-23/64"CH	CALL
432	16" - 5-1/2" CH	CALL
465, 1465	12"	CALL
480, 1480	16"	CALL
490, 1490	18"	CALL
510E, 515, 7300, 8010, 8200, 8210, 8300, Max Pro 1000	20"	CALL
515, 7300, 7400, 8010, 8300, Max Pro 1200	16"	CALL
528, 530	12-1/2"	CALL
2100	11"	NP-92
2120, 2140, 2160	15"	NP-92
2130, 2150, 2170	18"	NP-92
5200	19"	CALL
5280, 5300	19"	CALL
5400-24D	11"	CALL

Manufacturer's Model number Block Dia. Plate #

Tennant Cont.		
5400-26D	12-1/2"	CALL
5500	11"	CALL
5520	12"	CALL
5540	13"	CALL
5560	16"	CALL
5680-700D, 5700-700D, 7100-28D, 7200 Tight Aisle	14"	CALL
5680-800D, 5700, 800D, 7100-32D	16"	CALL
5680-900D, 5700-900D, 72000D	18"	CALL
8400, 8410, MaxPro 1200	16"	CALL
Powerline 17	15"	CALL
Powerline 20	18"	CALL
Power Trend 15	14"	NP-92
Power Trend 17	16"	NP-92
Power Trend 20	19"	NP-92
S250	12"/12-1/2"	CALL
Servomatic 17	15"-4-15/16"	CH CALL
Servomatic 26, 261	12"-4-23/24"	CH CALL
Servomatic 32	15"-4-23/64"	CH CALL
Viking 15	14"	CALL

Thoro-matic		
SE 15	13"	NP-92
SE 17	15"	NP-92
SE 20	18"	NP-92
SE 22	20"	NP-92
TM 12	10"-3-25/32"	CH CALL
TM 13	11"	NP-92
TM 15	13"	NP-92
TM 17, TM 17-TS	15"	NP-92
TM 20, TM 20 TS	18"	NP-92
TM 22	20"	NP-92
TM 300-17	15"	NP-92
TM 300-20	18"	NP-92

Tornado		
15	13"	NP-92
17	15"	NP-92
19	17"	NP-92
20-1	18"	NP-92
22	20"	NP-92
73 Series	12" - 5" CH	CALL
75 Series	14" - 5" CH	CALL
77 Series	16" - 5" CH	CALL
94 Series	12"	NP-92
96, 97	14"	NP-92
98	16"	NP-92
130, 131, 132	11" - 4" CH	CALL
280-15, 283-15	13"	NP-92
280-17, 283-17	15"	NP-92
280-19, 283-19	17"	NP-92
280-22, 283-22	20"	NP-92

Brushes - Machine Listings



Manufacturer's Model number	Block Dia.	Plate #
Tornado Cont.		
940 Series, 941	12"	NP-92
960, 961, 962	14"	NP-92
980, 981	16"	NP-92
990	20"	NP-92
6200, 6300	10" - 5" CH	CALL
6400, 6500	12" - 5" CH	CALL
6600, 6700	14" - 5" CH	CALL
6800, 6900	16" - 5" CH	CALL
95625 (21" AutoMite)	19" - 4-5/8"CH	CALL
95678/95679 (16" A.M)	14" - 4-5/8" CH	CALL
97800 (16" Series I)	14"	NP-92
97805 (18" Series I)	16"	NP-92
97810 (20" Series I)	18"	NP-92
97820 (14" Series I)	12"	NP-92
98405 (17" Series II)	15"	NP-92
98410 (19" Series II)	17"	NP-92
98415 (22" Series II)	20"	NP-92
98440 (Glazer 200/1500)	18"	CALL
98441 (Glazer 1100/1600)	18"	CALL
98445 (Glazer 1100/1400)	18"	CALL
98457 (Glazer 1500)	18"	CALL
98470 (16" Bi-Speed)	14"	NP-92
98473 (17" Bi-Speed)	15"	NP-92
98480 (20" Bi-Speed)	18"	NP-92
98653 (Tri-Drive 1017)	15"	NP-92
98656 (Tri-Drive 1020)	18"	NP-92
98663 (Tri-Drive 1517)	15"	NP-92
98666 (Tri-Drive 1520)	18"	NP-92
98672 (17" ES Deluxe)	15"	NP-92
98673	15"	NP-92
(ES8673 -17" Deluxe)		
98674 (20" ES Deluxe)	18"	NP-92
98675	18"	NP-92
(ES8675 - 20" Deluxe)		
98677 (1517SSM)	15"	NP-92
98682	15"	NP-92
(ES8682 17" Standard)		
98683	15"	NP-92
(ES8683 17" Standard)		
98684	18"	NP-92
(ES8684 - 20" Standard)		
98685	18"	NP-92
(ES8685 20" Standard)		
99125 (EZ-20 Floorkeeper)	19"	NP-92
99130 (EZ-24 Floorkeeper)	22"	NP-92
99300 (Floorkeeper 3800)	22"	CALL
99307 (26" Floorkeeper)	14"	CALL
99321 (24" Floorkeeper)	12"/13"	CALL
99351 (28" Floorkeeper)	14"/15"	CALL
99407	16"/16-1/2"	CALL
(33" Mid-Range Floorkeeper)		
99421	16"/16 1/2"	CALL
(32" Long-Range Floorkeeper)		
99430 (30" Floorkeeper)	16"	CALL
99450, 99451	18"	CALL
(36" Long-Range Floorkeeper)		

Manufacturer's Model number	Block Dia.	Plate #
Tornado Cont.		
Champion	10" -5-1/4"CH	CALL
Cyclone 14-1/2	12"	NP-92
Cyclone 16-1	14"	NP-92
Cyclone 18-1	16"	NP-92
Jumbo	14" -6-1/8"CH	CALL
Majestic	18" -6-1/8"CH	CALL
Royal	12" -5-1/4"CH	CALL
Standard	16" -6-1/8"CH	CALL
Windsor		
Lightning 175-17	15"	CALL
Lightning 175-20	18"	CALL
Merit 175-17 (MD-17)	15"	CALL
Merit 175-20 (MD-20)	18"	CALL
Merit MP13	11"	CALL
Merit MP15	13"	CALL
Merit MP17X	15"	CALL
Merit MP20X	18"	CALL
PowerTec 17	16"	CALL
PowerTec 20	18"	CALL
PowerTec 24	21"	CALL
PowerTec 26	13"	CALL
PowerTec 28	14"	CALL
PowerTec 32	16"	CALL
PowerTec 34	17"	CALL
Quick 32	15"	CALL
Saber 24	11"	CALL
Saber 26	12"	CALL
Saber 28	13"/13-1/2"	CALL
Saber Cutter 26	12"	CALL
Saber Glide 28	13"	CALL
Saber Glide 28/36	11"	CALL
Saber Glide 32, Cutter 32	15"	CALL
Saber 34	16"	CALL
Saber Compact 17	17"	CALL
Saber Compact 20	19"	CALL
Tracker AS34	17"	CALL
Trident Compact 17	16"	CALL
Trident Compact 20	19"	CALL
Trident TR28	14"	CALL
Trident TR34	17"	CALL



CLUTCH PLATES

Graco #	Description
4813P	Clutch Plate
NP-47	Clutch Plate
NP-92	Clutch Plate
P-200	Clutch Plate
P-500	Clutch Plate

MISCELLANEOUS


Graco #	Description
SC-83	Gimbal Motor
SC-84	Gimbal Motor Assy
BRC-32-L	16" Pad Lock 7 1/4"CH NO
CPT-17B	Blade Set for CPT-17 (No brackets)
CPT-17R	Brackets for CPT-17 (No blades)
L-800	Brush Locking Studs
CPT-17	Concrete Preparation Tool 17"
PH-2P	Replacement Disc
PH-3P	Ring - Pad Grab
BRE-4	Strip Set, Orange
PH-4	Centerlock Ring, Orange

ASSEMBLIES

Graco #	Description
BRC-24-IA	Plate & Pad Drive Assy.
PH-2	Bear Pad Holder Assy. Sm.
BRE-2	Brush Assy. Wood Hex Ends
BRE-1	Brush Assy. Wood Sq. Ends
BRI-21-I	Pad Drive Assy. (FSO I-21)
BRA-32-L	Pad Holder Assy.
BRA-18-L	Pad Holder Assy.
BRA-21-L	Pad Holder Assy.
BRA-24-L	Pad Holder Assy.
BRA-38-L	Pad Holder Assy.
BRC-20-IA	Plate & Pad Holder Assy.

PAD HOLDERS

Graco #	Description
PH-5L	Center Lok II L.H
PH-3	Center Pad Holder
PH-6-L	Center Pad Holder L.H
PH-6	Center Pad Holder R.H
PH-7	Center Lock Pad Holder
PH-5	Center Lok II R.H.
PH-6-D	Donut Pad Lock
PH-8	Pad Holder - Center Lock III
BRC-32-I	Pad Holder
BRC-21-I	Pad-Lok 10" No Ris No Plat



SPOTLIGHT
CONCRETE PREPARATION


CPT-17 - Concrete Preparation Tool 17"
 CPT-17B - Blade Set for CPT-17 (No Brackets)
 CPT-17R - Brackets for CPT-17 (No Blades)

PAD DRIVERS/PADS

PAD DRIVERS

This is the superior tufted pad driver choice, with heavy polypropylene strands trimmed offset at 1/2" and staple set. Tufts provide secure holding power by penetrating into the pad.

Graco #	Description
BRPD-11	Pad Driver 11" w/Riser, 1/2" Trim
BRPD-12	Pad Driver 12" w/Riser, 1/2" Trim
BRPD-13	Pad Driver 13" w/Riser, 1/2" Trim
BRPD-14	Pad Driver 14" w/Riser, 1/2" Trim
BRPD-15	Pad Driver 15" w/Riser, 1/2" Trim
BRPD-16	Pad Driver 16" w/Riser, 1/2" Trim
BRPD-17	Pad Driver 17" w/Riser, 1/2" Trim
BRPD-18	Pad Driver 18" w/Riser, 1/2" Trim
BRPD-19	Pad Driver 19" w/Riser, 1/2" Trim



Tri-Lok Pad Driver

TRI-LOK PAD DRIVERS

This design combines a Universal Clutch Plate, built-in riser and a triangular showerfeed system. The result is a cost-effective pad driver that can handle even the toughest jobs.

Graco #	Description
PD-15	Tri-Lok Pad Driver 15"
PD-16	Tri-Lok Pad Driver 16"
PD-17	Tri-Lok Pad Driver 17"
PD-18	Tri-Lok Pad Driver 18"
PD-19	Tri-Lok Pad Driver 19"
PD-20	Tri-Lok Pad Driver 20"

BRUSH PADS - NEOPRENE

GRACO#	OEM#	FITS	DESCRIPTION
BRC-20	885910-0	BP20	Pad Only
BRC-24	805950-3	TB24	Pad Only
BRC-32	895901-7	TB32	Pad Only
BRC-60	835905	2400's	Pad Only
BRC-80	835910	3200's	Pad Only
BRC-24-A	801357-5	TB-24	Block & Pad
BRC-32-A	891314-7	TB-32	Block & Pad
BRC-60-A	831804-1	2400's	Block & Pad
BRC-80-A	831308-2	3200's	Block & Pad



BRUSH STRIPS


Graco #	Description
BRE-4	12" Brush Strip Set - Orange
WV-7	Brush Strip 14"
WV-8	Brush Strip 18"
VCP-18	Brush Strip Set 12"
VCP-19	Brush Strip Set 16"
ASM40135	Strip Brush 16" (Abr) T7
ASM40138	Strip Brush 20" (Abr) T3
ASM40132	Strip Brush Green 13" (Abr) T7
ASM40131	Brush Poly Shower Rust 13" T7
ASM40130	Brush Nylon Wash Blue 13" T7
ASM40133	Brush Nylon Wash Blue 16" T7
ASM40134	Brush Poly Shower Rust 16" T7

MISCELLANEOUS


Graco #	Description
BR-669	Carpet Br. (Retrv) (752411)
BRC-575	Carpet Brush 575/576
SC-82	Gimbal Brush
BRA-24-B	Bassine Brush
BRC-18-B	Bassine Brush
BRC-21-B	Bassine Brush for TB-21
BRI-16-B	Bassine Brush for I-16
GS18B	Bassine Brush W/Clutch Plate
GS16B	Bassine Circular Brush
SC-83	Gimbal Motor
SC-84	Gimbal Motor Kit

SECTIONALS

Graco #	Description
BRC-32-N	Nylon Sectional Brush
BRC-60-N	Nylon Sectional Brush
BRC-60-A	Sectional Block Assy. Poly
BRC-24-A	Sectional Block Assy. Poly
BRC-32-A	Sectional Block Assy. Poly
BRC-80-A	Sectional Block Assy. Poly
BRC-24	Sectional Block Pad
BRC-32	Sectional Block Pad
BRC-60	Sectional Block Pad TB-60
BRC-80	Sectional Block Pad TB-80
BRC-60-P	Sectional Brush Pad Poly
BRC-32-P	Sectional Brush Poly (Spec. Order)
BRC-80-B	Sectional Brush Bassine
BRC-80-N	Sectional Brush Nylon
BRC-80-W	Sectional Brush Wire
AL-250-SP	Sectional Brush, Strata-Grit
BRC-24-W	Steel Wire Sect. Brush
BRC-32-W	Steel Wire Sectional
BRC-32-B	Bassine Brush Sect.
BRC-60-B	Bassine Sectional Brush



GRACO SPOTLIGHT BRUSH STRIPS



VCP-18 - Brush Strip Set 12"
 Replaces OEM #'s - 52282, 660932,
 ER217 & PP40

VCP-19 - Brush Strip Set 16"
 Replaces OEM #'s - 52264, 50681A,
 ER138 & PP40A